

# HD DIMENSIONAL PLASTISOL INKS



### **RECOMMENDED FABRICS**

100% Cotton Some 50/50 Cotton/Polyester Blends



#### **INK APPLICATION**

HD Dimensional Inks should be used right from the container without any modifications



#### **ADDITIVES**

Not recommended



#### **SCREEN MESH**

60-110 t/in (24-43 t/cm) monofilament



#### **EMULSION**

Any direct or indirect capillary film in the 200 to 400 micron range



#### **SQUEEGEE**

70-80 Durometer Sharp edge



## **CURE TEMPERATURES**

325°F (163°C) for 1 minute dependent on dryer speed and temperature settings



# **CLEAN-UP**

Any eco-friendly plastisol screen wash



#### **PRODUCT PACKAGING**

Quart, 1 gallon, 5 gallon, 30 gallon or 50 gallon containers



## STORAGE OF INK CONTAINERS

65° to 90°F (18°C to 32°C) Avoid storage in direct sunlight Keep containers well sealed



#### SDS

Refer to SDS prior to use

#### **FEATURES**

Produce special 3-D, heavy deposit, smooth matte finish prints.

Prints through thick stencils.

Extremely sharp edges can be produced.

Unique flash time will increase production and speed dwell time in the dryer.

#### **COLORS**

141 HD Clear 142 HD Base

143 HD White 144 HD Black

Colors may be created using Color Concentrates using 142 HD Base. Standard UltraMix® formulae may need adjusting to create darker colors.

#### **INK APPLICATION**

Set up the screens as with any print, making sure there is plenty of free mesh around the design. Choose the proper squeegee length and stroke distance for the design dimensions. Select a squeegee of 70-80 durometer. More control can be achieved using double and triple-ply blades. Angle the squeegee to increase deposit. The floodbar should be adjusted to provide maximum stencil loading. When the screen is flooded properly, it will take less effort for the squeegee to transfer the ink.

Use an off contact or peel setting to release ink from the stencil. Off-contact is a critical adjustment. If it is not high enough, the ink will not release from the screen. Set the print and flood speed to the slowest setting; then increase the speed, as the design permits. Apply minimal squeegee pressure; only enough to transfer the ink. Too much pressure will push the ink into the fabric. The idea is to lay the ink on the surface. For maximum height, flash the print and stack on another layer. Depending on the thickness of the first print, additional prints may require increase in off contact. By layering the print, image results are better controlled.

## IMPORTANT INFORMATION

HD Dimensional Inks are not low bleed plastisols and are not recommended for use on poly/cotton or 100% poly fabrics that may be prone to dye migration. Always test print the fabric to be printed before beginning production. Bleeding or dye migration may not occur right away.

Test dryer temperatures and wash test printed product before and during a production run.

# LEGAL DISCLAIMER

Recommendations and statements made are based on International Coatings' research and experience. Since International Coatings does not have any control over the conditions of use or storage of the product sold, International Coatings cannot guarantee the results obtained through use of its products. All products are sold and samples given without any representation of warranty, expressed or implied, of fitness for any particular purpose or otherwise, and upon condition that the buyer shall determine the suitability of the product for its own purpose. This applies also where rights of third parties are involved. It does not release the user from the obligation to test the suitability of the product for the intended purpose and application.

REV. 2400001